



STYLUS CLEANER

We recommend that you clean the stylus before each play or anytime you hear distortion or mis-tracking.

INSTRUCTIONS FOR USE:

1. Uncap the STYLUS CLEANER bottle.
2. Gently apply the STYLUS CLEANER to the stylus tip using the applicator brush that is built into the cap top. The brush is very soft and will conform to the shape of the cantilever tube and stylus tip. Always start at the point where the cantilever tube enters the cartridge body and sweep the brush towards the stylus tip.
3. Two or three brush strokes are normally all that is necessary to clean dust and debris off the stylus tube and tip assembly.

How and when to use the flat-topped black handled brush:

Use this brush if a stylus tip has not been receiving regular cleaning; contamination may have built up and become baked on or "pyrolysed". Apply STYLUS CLEANER to the black brush with the soft brush in the bottle. Then gently raise the black brush under the stylus tip until contact is made and gently pull it along the stylus tip in the same direction as the record would be traveling. Even though the brush pile is very dense, the brush fibers will conform to the shape of the stylus and will help to mechanically remove the baked on material.

Occasionally, you will experience just a small ball of light puffy powder on the stylus tip. To remove this, the black brush may be used dry as a safe and effective cleaner

4. Recap the STYLUS CLEANER bottle to prevent loss due to spill or evaporation.

Following cleaning, we recommend using STYLAST STYLUS TREATMENT for extending the stylus life and improving tracking ability.

Note: Please keep LAST STYLUS CLEANER and all other record and stylus care products away from children.

The LAST Factory
2015 Research Drive
Livermore, CA 94550 U.S.A.
925-449-9449
www.lastfactory.com