



STYLAST™ STYLUS TREATMENT

INSTRUCTIONS FOR USE:

1. First clean the stylus thoroughly with LAST STYLUS CLEANER.
2. Uncap the STYLAST bottle.
3. Using the applicator brush that is built into the cap, gently apply the treatment to the stylus tip. One or two strokes, using a back-to-front motion is sufficient. Never brush from the front to back.

It is only necessary to touch the diamond tip gently. Do NOT use any force or pressure on the stylus tip/cantilever assembly.

How and when to use the flat-topped black handled brush:

Occasionally you will find a small ball of light puffy powder on the stylus tip. To remove this, the black brush may be used dry as a safe and effective cleaner. Gently raise the black brush under the stylus tip until contact is made and gently pull it along the stylus tip in the same direction as the record would be traveling. Even though the brush pile is very dense, the brush fibers will conform to the shape of the stylus to dry clean it.

4. Recap the SYLAST bottle to prevent loss or evaporation.
5. The stylus is now ready for playing a record.
6. For best performance and longest stylus life, STYLAST should be used prior to every record play.

Note: Please keep STYLAST and all other record and stylus care products away from children.

The LAST Factory
2015 Research Drive
Livermore, CA 94550 U.S.A.
925-449-9449
www.lastfactory.com